


MODEL: PN-630



L2240

PARTS LIST(PN-630)

*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No., PART No., AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	US0406B	UM.HD.BOLT	29	22302901	STEPPED PIN			
2	FW0412W	FLAT WASHER	30	ER0300H	E RING			
3	22300301	EXHAUST COVER	31	22303101	TRIGGER			
4	HS0520B	HEX.SOC.HD.BOLT	32	22303201	TRIGGER			
5	SW0500W	SPRING WASHER	33	22303301	STEPPED PIN			
6	22300601	CAP	34	22303401	PIN			
7	22300701	GASKET	35	22303501	SPRING			
8	22300801	SEAL	36	22403601	STOPPER			
9	22300901	SPRING	37	22403701	BRACKET			
10	OR1220R	O RING(12.2*2)	39	22303901	AIR PLUG			
11	OR2224R	O RING (P22)	40	US0410B	UM.HD.BOLT			
12	22301201	PISTON HEAD VALVE	41	SW0400W	SPRING WASHER			
13	OR0830R	O RING(8*3)	42	HS0414B	HEX.SOC.HD.BOLT			
14	OR1730R	O RING(17*3)	43	HS0408B	HEX.SOC.HD.BOLT			
15	22301501	COLLAR	44	22404401	DRIVER GUIDE COVER			
16	OR3225R	O RING(32*2.5)	45	22404501	DRIVER GUIDE			
17	OR1230R	O RING(12*3)	46	22404601	MAGAZINE			
18	22301801A	PISTON ASSEMBLY	47	22404701	SPACER PLATE			
19	22301901	CYLINDER	48	22404801	SPACER PLATE			
20	22302001	BUMPER	49	FH0306B	FLAT.HD.BOLT			
21	22302101	BODY	50	22405001	MAGAZINE COVER			
22	22302201	JOINT GUIDE	51	22405101	PUSHER			
23	OR0919R	O RING(P9)	52	22405201	PUSHER			
24	22302401	TRIGGER VALVE HEAD	53	22405301	SPRING			
25	22302501	TRIGGER VALVE STEM	54	22405401	PUSHER			
26	OR4212H	O RING(4.2*1.25)	55	22405501	PUSHER STOP			
27	22302701	TRIGGER VALVE GUIDE	56	22405601	STOP PLATE			
28	22302801	SPRING	57	22405701	MAGAZINE STOP			

L2240

2002/8/2